

MOOG

VIDEOLARM

© 2012, Moog Videolarm, Inc. All Rights Reserved



With Sunshield

Stainless Steel Dome

Rugged Environmental Camera Enclosure Housings

www.moogvideolarm.com

Installation and Operation Instructions for the following models:

SSDP75CN2Y	Stainless steel dome, pendant mount, 24Vac input, heater and blower, sunshield
SSDP75CN2	Stainless steel dome, pendant mount, 24Vac input, heater and blower
SSDP75CN	Stainless steel dome, pendant mount, no electronics

Before attempting to connect or operate this product, please read these instructions completely.
To be used with the 81-IN5481 Instruction Manual.

81-IN5482
03-21-2012

IMPORTANT SAFEGUARDS

- 1 Read these instructions.
- 2 Keep these instructions.
- 3 Heed all warnings
- 4 Follow all instructions.
- 5 Do not use this apparatus near water.
- 6 Clean only with damp cloth.
- 7 Do not block any of the ventilation openings. Install in accordance with the manufacturers instructions.
- 8 Cable Runs- All cable runs must be within permissible distance.
- 9 Mounting - This unit must be properly and securely mounted to a supporting structure capable of sustaining the weight of the unit.

Accordingly:

- a. This installation should be made by a qualified service person and should conform to all local codes.
 - b. Care should be exercised to select suitable hardware to install the unit, taking into account both the composition of the mounting surface and the weight of the unit.
- 10 Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
 - 11 Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. When the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
 - 12 Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
 - 13 Only use attachment/ accessories specified by the manufacturer.
 - 14 Use only with a cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/ apparatus combination to avoid injury from tip-over.
 - 15 Unplug this apparatus during lighting storms or when unused for long periods of time.
 - 16 Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Be sure to periodically examine the unit and the supporting structure to make sure that the integrity of the installation is intact. Failure to comply with the foregoing could result in the unit separating from the support structure and falling, with resultant damages or injury to anyone or anything struck by the falling unit.

UNPACKING

Unpack carefully. Electronic components can be damaged if improperly handled or dropped. If an item appears to have been damaged in shipment, replace it properly in its carton and notify the shipper.

Be sure to save:


- 1 The shipping carton and packaging material.
They are the safest material in which to make future shipments of the equipment.
- 2 These Installation and Operating Instructions.

SERVICE

If technical support or service is needed, contact us at the following number:

TECHNICAL SUPPORT
AVAILABLE 24 HOURS
1 - 800 - 554 -1124

SAFETY PRECAUTIONS



The lightning flash with an arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of non-insulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk to persons.

Este símbolo se piensa para alertar al usuario a la presencia del "voltaje peligroso no-aislado" dentro del recinto de los productos que puede ser un riesgo de choque eléctrico.

Ce symbole est prévu pour alerter l'utilisateur à la présence "de la tension dangereuse" non-isolée dans la clôture de produits qui peut être un risque de choc électrique.

Dieses Symbol soll den Benutzer zum Vorhandensein der nicht-Isolier "Gefährdungsspannung" innerhalb der Produkteinschließung alarmieren die eine Gefahr des elektrischen Schlages sein kann.

Este símbolo é pretendido alertar o usuário à presença "di tensão perigosa non-isolada" dentro do cerco dos produtos que pode ser um risco de choque elétrico.

Questo simbolo è inteso per avvertire l'utente alla presenza "di tensione pericolosa" non-isolata all'interno della recinzione dei prodotti che può essere un rischio di scossa elettrica.



The exclamation point within an equilateral triangle is intended to alert the user to presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

Este símbolo del punto del exclamation se piensa para alertar al usuario a la presencia de instrucciones importantes en la literatura que acompaña la aplicación.

Ce symbole de point d'exclamation est prévu pour alerter l'utilisateur à la présence des instructions importantes dans la littérature accompagnant l'appareil.

Dieses Ausruf Punktsymbol soll den Benutzer zum Vorhandensein de wichtigen Anweisungen in der Literatur alarmieren, die das Gerät begleitet.

Este símbolo do ponto do exclamation é pretendido alertar o usuário à presença de instruções importantes na literatura que acompanha o dispositivo.

Questo simbolo del punto del exclamation è inteso per avvertire l'utente alla presenza delle istruzioni importanti nella letteratura che accompagna l'apparecchio.



Limited Warranty for Moog Videolarm Products

Moog Videolarm warrants these products to be free from defects in material or workmanship as follows:

PRODUCT CATEGORY	PARTS \ LABOR
All Enclosures and Electronics*	Five (5) Years
Poles/PolEvators™/CamEvator	Three (3) Years
Warrior Series™/Q-View™/IR Illuminators	Five (5) Years
SView Series™	Five (5) Years **6 months if used in auto scan/tour operation
Controllers	Five (5) Years
Power Supplies	Five (5) Years
EcoKit	Three (3) Years
Accessory Brackets	Five (5) Years
Liberty Dome	Three (3) Years
*DeputyDome™, NiteTrac™, Igloo Dome, PurgeDome™	Three (3) Years **6 months if used in auto scan/tour operation

During the labor warranty period, to repair the Product, Purchaser will either return the defective product, freight prepaid, or deliver it to Moog Videolarm Inc. Decatur GA. The Product to be repaired is to be returned in either its original carton or a similar package affording an equal degree of protection with a RMA # (Return Materials Authorization number) displayed on the outer box or packing slip. To obtain a RMA# you must contact our Technical Support Team at 800.554.1124, extension 101. Moog Videolarm will return the repaired Product freight prepaid to Purchaser. Moog Videolarm is not obligated to provide Purchaser with a substitute unit during the warranty period or at any time. After the applicable warranty period, Purchaser must pay all labor and/or parts charges.

The limited warranty stated in these product instructions is subject to all of the following terms and conditions.

TERMS AND CONDITIONS

1. NOTIFICATION OF CLAIMS: WARRANTY SERVICE: If Purchaser believes that the Product is defective in material or workmanship, then written notice with an explanation of the claim shall be given promptly by Purchaser to Moog Videolarm. All claims for warranty service must be made within the warranty period. If after investigation Moog Videolarm determines the reported problem was not covered by the warranty, Purchaser shall pay Moog Videolarm for the cost of investigating the problem at its then prevailing per incident billable rate. No repair or replacement of any Product or part thereof shall extend the warranty period of the entire Product. The specific warranty on the repaired part only shall be in effect for a period of ninety (90) days following the repair or replacement of that part or the remaining period of the Product parts warranty, whichever is greater.

2. EXCLUSIVE REMEDY: ACCEPTANCE: Purchaser's exclusive remedy and Moog Videolarm's sole obligation is to supply (or pay for) all labor necessary to repair any Product found to be defective within the warranty period and to supply, at no extra charge, new or rebuilt replacements for defective parts.

3. EXCEPTIONS TO LIMITED WARRANTY: Moog Videolarm shall have no liability or obligation to Purchaser with respect to any Product requiring service during the warranty period which is subjected to any of the following: abuse, improper use, negligence, accident, lightning damage or other acts of God (i.e., hurricanes, earthquakes), modification, failure of the end-user to follow the directions outlined in the product instructions, failure of the end-user to follow the maintenance procedures recommended by the International Security Industry Organization, written in product instructions, or recommended in the service manual for the Product. Furthermore, Moog Videolarm shall have no liability where a schedule is specified for regular replacement or maintenance or cleaning of certain parts (based on usage) and the end-user has failed to follow such schedule; attempted repair by non-qualified personnel; operation of the Product outside of the published environmental and electrical parameters, or if such Product's original identification (trademark, serial number) markings have been defaced, altered, or removed. Moog Videolarm excludes from warranty coverage Products sold AS IS and/or WITH ALL FAULTS and excludes used Products which have not been sold by Moog Videolarm to the Purchaser. All software and accompanying documentation furnished with, or as part of the Product is furnished "AS IS" (i.e., without any warranty of any kind), except where expressly provided otherwise in any documentation or license agreement furnished with the Product. Any cost associated with removal of defective product and installation of replacement product is not included in this warranty.

4. PROOF OF PURCHASE: The Purchaser's dated bill of sale must be retained as evidence of the date of purchase and to establish warranty eligibility.

DISCLAIMER OF WARRANTY

EXCEPT FOR THE FOREGOING WARRANTIES, Moog Videolarm HEREBY DISCLAIMS AND EXCLUDES ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO ANY AND/OR ALL IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND/OR ANY WARRANTY WITH REGARD TO ANY CLAIM OF INFRINGEMENT THAT MAY BE PROVIDED IN SECTION 2-312(3) OF THE UNIFORM COMMERCIAL CODE AND/OR IN ANY OTHER COMPARABLE STATE STATUTE. Moog Videolarm HEREBY DISCLAIMS ANY REPRESENTATIONS OR WARRANTY THAT THE PRODUCT IS COMPATIBLE WITH ANY COMBINATION OF NON-Moog Videolarm PRODUCTS OR NON-Moog Videolarm RECOMMENDED PRODUCTS PURCHASER MAY CHOOSE TO CONNECT TO THE PRODUCT.

LIMITATION OF LIABILITY

THE LIABILITY OF Moog Videolarm, IF ANY, AND PURCHASER'S SOLE AND EXCLUSIVE REMEDY FOR DAMAGES FOR ANY CLAIM OF ANY KIND WHATSOEVER, REGARDLESS OF THE LEGAL THEORY AND WHETHER ARISING IN TORT OR CONTRACT, SHALL NOT BE GREATER THAN THE ACTUAL PURCHASE PRICE OF THE PRODUCT WITH RESPECT TO WHICH SUCH CLAIM IS MADE. IN NO EVENT SHALL Moog Videolarm BE LIABLE TO PURCHASER FOR ANY SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES OF ANY KIND INCLUDING, BUT NOT LIMITED TO, COMPENSATION, REIMBURSEMENT OR DAMAGES ON ACCOUNT OF THE LOSS OF PRESENT OR PROSPECTIVE PROFITS OR FOR ANY OTHER REASON WHATSOEVER.



Electrical Specifications

Power 24VAC
Class 2 Only

SS Dome



24 VAC
92 Watts

Accessories: Heater: 50 Watts, Blower: 2 Watt
Camera Power: (See Camera Specifications): 40 Watts Max
Tools Required: .100" Flat Head Screwdriver
Phillips Head Screwdriver

English



24 VAC
92 Vatos

De Accesorios: Calentador: 50 Watts, Blower: 2 Vatio
Energía De la Cámara fotográfica De : (Véase Las
Especificaciones De la Cámara fotográfica): 40 Vatos
De Herramientas Máximas

Español

Requeridas: Destornillador Principal Phillips Del Destornillador
Principal Plano Del 100"



24 VCA
92 Watts

D'Accessoires : Réchauffeur : 50 Watts, Ventilateur : 2 watts.
Puissance D'Appareil-photo : (Voir Les Caractéristiques
D'Appareil-photo) : 40 Watts De Maximum

Français

Les Outils Ont exigé : Tournevis Principal Phillips De Tournevis
Principal Plat De 100".



24 VAC
92 Watt

Zusatzgerät-: Heizung: 50 Watts, Blower: 2
Watt-Kamera-Energie: (Sehen Sie Kamera-Spezifikationen):
40 Watt Maximale Werkzeug-Erfordert: 100"Flacher
Hauptschraubenzieher-Kreuzkopfhauptschraubenzieher

Deutsch



24 VAC
92 Watts

De Acessórios: Calefator: 50 Watts, Blower: 2 Watt
Poder Da Câmera De : (Veja Especificações Da Câmera):
40 Watts De Ferramentas Máximas Requereram: Chave de
fenda Principal Phillips Da Chave de fenda Principal Lisa Do 100"

Portuguese






24 VCA
92 Watt

Di Accessori: Riscaldatore: 50 Watts, Blower: 2 Watt
Alimentazione Della Macchina fotografica Da :
(Veda Le Specifiche Della Macchina fotografica): 40 Watt
Di Attrezzi Massimi Hanno richiesto: Cacciavite Capo "phillips"
Del Cacciavite Capo Piano Del 100"


Italiano

Contents of Box



* NOT included with E or 12V models


1



Wall mount bracket is designed for straight conduit. If this fitting is desired, install it first.

- El soporte del montaje de la pared se diseña para el conducto recto. Si se desea esta guarnición, instálela primero.
- La parenthèse de bâti de mur est conçue pour le conduit droit. Si cet ajustage de précision est désiré, installez-le d'abord.
- Wandeinfassungshaltewinkel ist für gerades Rohr bestimmt. Wenn diese Befestigung gewünscht wird, bringen Sie sie zuerst an.
- O suporte da montagem da parede é projetado para a canalização reta. Se este encaixe é desejado, instale-o primeiramente.
- La staffa del supporto della parete è progettata per il condotto diritto. Se questo montaggio è voluto, installilo in primo luogo.


2



Run connection wires through mount and attach to wall with suitable mounting hardware.

- Funcione con los alambres de la conexión a través del montaje y átelos a la pared con hardware de montaje conveniente.
- Courez les fils de raccordement par le bâti et les attachez au mur avec le matériel de support approprié.
- Lassen Sie Anschlussdrähte durch Einfassung laufen und bringen Sie zur Wand mit verwendbarer Montage-Hardware an.
- Funcione fios da conexão através da montagem e una-os à parede com ferragem de montagem apropriada.
- Faccia funzionare i legare del collegamento tramite il supporto ed attacchi alla parete con i fissaggi di montaggio adatti.


3



Trim wires no longer than 5" outside mount.

- Alambres del ajuste no más que" montaje del exterior 5.
- Fils d'équilibre plus que » bâti de l'extérieur 5.
- Ordnungsdrähte nicht mehr als" Einfassung der Außenseite 5.
- Fios da guarnição já não do que da" montagem parte externa 5.
- Legare della disposizione più che,, supporto della parte esterna 5.


4



If required, install provided sunshield with phillips screwdriver.

- Si procede, instale el sunshield proporcionado con destornillador Phillips.
- S'il y a lieu, installez le sunshield fourni avec le tournevis Phillips.
- Wenn erforderlich bringen Sie zur Verfügung gestelltes sunshield mit Kreuzkopfschraubenzieher an.
- Se requerido, instale o sunshield fornecido com chave de fenda Phillips.
- A richiesta, installi il sunshield fornito con il cacciavite "phillips".


5



Secure lanyard from dome housing to clip on wall mount.

- Acollador seguro de la bóveda que contiene al clip en el montaje de la pared.
- Lanière bloquée du dôme logeant à l'agrafe sur le bâti de mur.
- Sichere Abzuglinie von der Haube, die zum Klipp auf Wandbefestigung unterbringt.
- Colhedor seguro da abóbada que abriga ao grampo na montagem da parede.
- Cordicella sicura dalla cupola che alloggia alla clip sul supporto della parete.


6



Complete all wiring connections.

- Termine todas las conexiones del cableado.
- Accomplissez tous les raccordements de câblage.
- Schließen Sie alle Verdrahtungsanschlüsse ab.
- Termine todas as conexões da fiação.
- Completi tutti i collegamenti dei collegamenti.


7



Rotate housing assembly clockwise into wall mount fitting.

- Gire el montaje de la cubierta a la derecha en la guarnición del montaje de la pared.
- Tournez le logement dans le sens des aiguilles d'une montre dans l'ajustage de précision de bâti de mur.
- Drehen Sie Gehäuse nach rechts in Wandbefestigungsbefestigung.
- Gire o conjunto da carcaça no sentido horário no encaixe da montagem da parede.
- Giri l'assemblea dell'alloggiamento in senso orario nel montaggio del supporto della parete.


8



Refer to manual #81-IN5481 for camera installation instructions.

- Refiera a #81-IN5481 manual para las instrucciones de instalación de la cámara.
- Réferez-vous à #81-IN5481 manuel pour des instructions d'installation d'appareil-photo.
- Beziehen Sie sich auf manuelles #81-IN5481 für KameraMontagevorschriften.
- Refira #81-IN5481 manual para instruções de instalação da câmera.
- Riferisca a #81-IN5481 manuale per le istruzioni di installazione della macchina fotografica.


9



After Camera installation. Attach lanyard to the trim ring assembly.

- Después de la instalación de la cámara. Ate el acollador al montaje del anillo del ajuste.
- Après installation d'appareil-photo. Attachez la lanière à l'anneau d'équilibre.
- Nach Kamerainstallation. Bringen Sie Abzuglinie zum OrdnungsRing an.
- Após a instalação da câmera. Una o colhedor ao conjunto do anel da guarnição.
- Dopo l'installazione della macchina fotografica. Attacchi la cordicella all'assemblea dell'anello della disposizione.


10



Fasten trim ring assembly to main housing with a phillips screwdriver.

- Sujete el montaje del anillo del ajuste a la cubierta principal con un destornillador Phillips.
- Attachez l'anneau d'équilibre au logement principal avec un tournevis Phillips.
- Befestigen Sie OrdnungsRing am Hauptgehäuse mit einem Kreuzkopfschraubenzieher.
- Prenda o conjunto do anel da guarnição à carcaça principal com uma chave de fenda Phillips.
- Fissi l'assemblea dell'anello della disposizione ad alloggiamento principale con un cacciavite "phillips".

Replacement Parts List



Product Registration/Warranty

Thank you for choosing Moog Videolarm. We value your patronage and are solely committed to providing you with the highest quality products available and superior customer service.

Should a problem arise, rest assure that Moog Videolarm stands behind its products by offering impressive warranty plans: 3 Years on all Housings, Poles, Power Supplies, and Accessories and 5 Years on camera systems (SView, QView, Warriors), and InfraRed Illuminators.



Register Your Products Online

Take a few moments and validate your purchase via the Online Product Registration Form at
www.videolarm.com/productregistration.jsp

Register your recent Moog Videolarm purchases and benefit from the following:

- Simple and Trouble-Free RMA process
- Added into customer database to receive product updates / news
- Eliminate the need to archive original purchase documents:
Receipts, Purchase Orders, etc...